

User Manual

Dakota Micro® AHD 9" Quad Monitor



Always read the manual prior to operating this equipment. Also, please follow all safety signs and precautions.



Table of Contents

Included Components 3
Optional Components
Standard Features
Monitor
Monitor Installation & Mounting
Mounting Precautions
Universal Bracket Mounting4
Finalizing Universal Bracket Installation4
Power
Supplying Power with 12v Power Adapter 4
Hardwire Power Adapter4
Fuses
Monitor & Remote Operations 4
Monitor Operations 4
Remote Operations
Monitor Wire Harness Details
Harness Components
Event Trigger Wire Color Guide
Event Trigger Wires Explained5
Menu Settings
Specifications
Warnings7
Product Warranty/Repair Process
Consumer Limited Warranty
Disclaimer
Contact Us



Included Components

Description	Picture
Dakota Micro® AHD 9" Quad Monitor	
Dakota Micro® AHD 9" Quad Monitor Wire Harness PN: DM-H9QMWH	
Dakota Micro [®] AHD 9" Quad Monitor Remote PN: DM-H9QRMT	
Dakota Micro [®] 9" Monitor Sun Shade PN: DM-9Shade	
Dakota Micro [®] 9" Monitor U-bracket and Hardware PN: DMAC-9M-Bracket	
Dakota Micro [®] 2.1 Barrel Male to Auxiliary Power PN: DM-12V	\sim

Optional Components

Description	Picture
Dakota Micro [®] 2.1 Barrel Male to Electrical Outlet	
Power	
PN: DM-PA3	

Standard Features

Monitor

- Features the latest in Analog HD technology
- View 1,2,3,or 4 cameras at the same time
- LED backlit
- Compatible with NTSC or PAL cameras, simultaneously
- Compatible with AHD or CVBS cameras, simultaneously
- Advanced LCD technology allows you to clearly see your image from any angle
- Mirror the view of any of your cameras for use as a backup camera
- 2-year warranty
- 16:9 aspect ratio
- 4 Camera Inputs
- Event triggers for each camera allow for triggered events to bring your camera to full view (I.E. putting the vehicle in reverse)
- Color, brightness, contrast, and volume controls that allow comprehension for use in different environments.



Monitor Installation & Mounting

Mounting Precautions

Remove your monitor carefully from packaging and inspect all mounting hardware. Mounting location is the most important part of the monitor installation as it ensures you the maximum visual benefit from your Dakota Micro system. With that said, when installing your monitor, ensure to follow these three (3) precautions:

- 1. The monitor is out of direct sunlight. This will prolong the life of the unit as well as ensure optimum visibility.
- 2. The monitor does not obstruct view.
- 3. The monitor does not interfere with the normal operation of equipment.

Warning: Dakota Micro, Inc. is not responsible for any damages caused to your monitor or yourself due to the improper installation or use of a suction cup monitor mount, whether it be product sold by DM or product purchased from another source.

Universal Bracket Mounting

- 1. Hold monitor U-bracket in place on monitor.
- 2. Attach bracket with included wing bolts.

Finalizing Universal Bracket Installation

- 1. With the mount and monitor attached, find, and mark the desired position for the monitor.
- 2. Remove the monitor from the mount.
- 3. Attach the monitor to the mount and tighten the wing bolts. (DISCLAIMER: Use ONLY the bolts included in kit, bolts any longer will damage your monitor)

Power

Supplying Power with 12v Power Adapter

- 1. Attach the power input connector on monitor to your included 12v cigarette lighter power adapter.
- 2. Plug Cigarette lighter adapter into 12v power source.

Hardwire Power Adapter

- 1. If you would like to hardwire your power supply, please contact your local Dakota Micro, Inc. dealer for available hardwire power adapters (PN: DM-HDWRE)
- 2. Dakota Micro hardwire power adapters have a maximum circuit capability of 5 amp.

Fuses

- 1. There is a small in-line glass fuse located on the red power wire. When replacing this fuse, use a MAX 3 AMP glass fuse.
- 2. There is a small glass fuse located on the inside tip of the 12v portion of the power adapter (PN: DM-12v). When replacing this fuse, use a MAX 4amp glass fuse.

Monitor & Remote Operations

Monitor Operations



1		Single camera image- one (1) camera image at a time		
2		Split Screen- two (2) camera images at a time		
3		Quad Screen- four (4) camera images at a time		
4	- Key	To Decrease parameter		
5	+ Key	To Increase parameter		
6	MENU	Allows users to access the menu. Once in the menu, toggles through menu options		
7	AV	Each button press switches between AV1, AV2, AV3, & AV4. Also, selects menu options within sub menus.		
8	Power	Powers Monitor ON and OFF (2 Second delay)		
	BY: SJE	V3.3	REV: 02/21/24	



Remote Operations

inte op				
0	POWER ON/OFF			
MODE	Switches between video channels			
	Navigation Arrow			
	Displays Menu			
СН	Camera/ Channel 1 Full Screen			
CH2	Camera/ Channel 2 Full Screen			
СНЗ	Camera/ Channel 3 Full Screen			
CIL4	Camera/ Channel 4 Full Screen			



Monitor Wire Harness Details

Harness Components

- 1. Input to Monitor
- 2. AV 1-4 Event Trigger Wires
- 3. Fuse
- 4. Power Input
- 5. RCA- Video Output
- 6. AV1- Audio/Video Input
- 7. AV2- Video Input
- 8. AV3- Video Input
- 9. AV4- Video Input

Event Trigger Wire Color Guide


- 1. Camera 1- Green
- 2. Camera 2- Purple
- 3. Camera 3- Gray
- 4. Camera 4- White

Event Trigger Wires Explained

Event trigger wires can be attached to any 12v or 24v positive output event switch or supply. The event circuit should be neutral in its normal state and change to HIGH (12v or 24v) when the event is active. This will cause the monitor to automatically switch to that camera, regardless of the state of the monitor (i.e. ON/OFF or different channel selection). Up to 3 cameras can be triggered on and simultaneously displayed at the same time. For example, if you have trigger wires 2 and 4 hooked up to a positive event, a split screen of cameras 2 and 4 will be displayed. You can also set a camera to be a priority so when it is triggered it will override any other image to full screen. See Menu Setting for more details.

Menu Settings

- 1. Press the MENU key on the face of the monitor or remote. MENU key also acts as "enter" key once within the menu.
- Use the AV key on the monitor (up and down arrows on remote) to select an item under each section. Selected menu items turn blue.
- 3. Use or + on the monitor (left or right arrow on remote) to change the value of the highlighted item.
- To exit: Press the MENU button on monitor multiple times until the menu goes away. Allow monitor to time out (approximately 10 seconds).



DAKOTA MICRO

	Display Adjustment:
□ Display Setting □ Display Adjustment S Loop Preview Off > Power On Mode Off > Auto Dimmer > Display Mode Setting up Orf > Auto Dimmer > Display Mode Setting up Off Off 1 2 3 4 Confirm Camera Option Install Select Mode1 Mode2 Reverse Line Off 1 1 2 3 4 Reverse priority 0ff 1 2 3 Confirm Cancel ** ** ** ** ** ** ** ** ** ** ** **	 Display Adjustment: <u>Scene Mode:</u> Adjusts look of entire display-highlight, film, brilliance, cool, warm, custom. Adjustment of brightness, contrast, saturation, & hue of chosen scene also available <u>Image Adjust:</u> Allows adjustment of individual cameras- brightness, contrast saturation, hue. You can also individually flip each camera. Loop Preview: Set Auto rotation time between screen views – OFF, 3,5,8,10, or 15 seconds Power On Mode: Select the default camera view when you power on. Select from cameras: 1,2,3,4,1/2,3/4, H, and Quad Installation Mode: Choose from more default camera view options. <u>Install Select:</u> Mode 1 is regular screen view and Mode 2 flips screen upside down. <u>Reverse Line:</u> Check the boxes of which cameras (or none) you'd like to view the reverse guidelines. Note, reverse lines can only be displayed in full screen one at a time. <u>Turn Light Mode:</u> N/A <u>Reverse Priority:</u> Select which single camera overrides any other rigger event when reversing Auto Dimmer: Mark "On" if you want the monitor to automatically dim in low-light conditions Display Mode: Allows adjustment of how cameras are displayed on screen as well as background & border colors
System Setting Language Setting power saving mode Restore Factory System Upgrade Centure Cancel	Language Setting: Select Language Power Saving Mode: Set Power Saving Mode duration- Off, 10min, 30min, 1hr, 2hr Restore Factory: Restore monitor to factory settings System Upgrade: Install firmware updates (SD card would need to be supplied by manufacturer to update; updates generally not needed)

Specifications

LCD Mon	itor				
Screen Si	ze	16:9 Digital Par	16:9 Digital Panel		
Overall S	ize	9.25in(235mm)	9.25in(235mm) (L) x 6.1in(155mm) (H) x 1.44in(36.5mm) (D)		
Weight		862g	862g		
Power In	Power Input		DC 12-24v		
Color Sys	Color System		NTSC/PAL auto switch		
Operatin	g Temp.	-4°F(-20°C) ~15	-4°F(-20°C) ~158°F(70°C)		
Brightnes	SS	550cd/m ²	550cd/m ²		
Resolutio	on (HxV)	1024(H)x600(V	1024(H)x600(V)		
Contrast		500:1	500:1		
Viewing Angle		L/R: 65° Up: 55	L/R: 65° Up: 55° Down: 55°		
Operatin	Operating Voltage		12-24V		
Lighting Source		LED Backlight	LED Backlight		
Environm	nental Rating	IP50	IP50		
Video Ou	tput Port	1 RCA Video Ou	1 RCA Video Out- CVBS (Analog) ONLY		
Video Inp	Video Input Port 4 AHD video input channels				
MES	BY: SJE	V3.3	REV: 02/21/24	Page 6	



Warnings

- 1. When selecting a camera system from Dakota Micro, Inc., be sure to utilize the appropriate system for your use. AgCam[®], EnduraCam[®] and InnoPro[®] cameras are designed for high impact, moisture, vibration, and a variety of other rough conditions. OverView[®] and RazerCam[™] cameras and kit components are designed for light use, low vibration, and low moisture. OverView[®] and RazerCam[™] equipment is not warranted when used in situations outside of the above-mentioned parameters. We always request that customers keep in mind that our less expensive OverView[®] and RazerCam[™] product line is cheaper because it does not feature the reliability and durability of our AgCam[®] and EnduraCam[®] lines. The warranty available on these products reflects that durability.
- To avoid electrical shock and maintain optimal functionality, do not open the enclosures. High voltage may be present and there are no user serviceable parts inside. All warranties will be void should any enclosures be tampered with in any way.
- 3. Do not use any harsh chemical solvents, cleaning agents or corrosive detergent to clean away dirt on the surface of the screen or lens.
- 4. On AgCam[®] and EnduraCam[®] products, the photo-chromic camera lenses have been made impact-resistant and have been drop-ball tested according to Sec. 3.84,21 CRF BUT ARE NOT UNBREAKABLE. Because they have been hardened chemically, they show no stress pattern. Inspect your lenses frequently. Chipped or scratched surfaces will reduce protection. Such lenses should be replaced only by the manufacturer.
- 5. Power to cameras is not interrupted by turning off monitor; 12v power source must be terminated when not in use to avoid battery drain. To avoid this problem be sure when hard wiring a unit, use a fused circuit.
- 6. Do not use your Dakota Micro, Inc. camera system for anything other than legal surveillance and observation uses. Dakota Micro, Inc. is not liable for any illegal or nefarious usage.

Product Warranty/Repair Process

- 1. For Technical Support call 1 701-538-4403 OR email techsupport@dakotamicro.com
- 2. Technician will assist in troubleshooting product malfunction.
- 3. If product malfunction cannot be remedied and a repair is deemed necessary, Technician will issue a case number.

IMPORTANT NOTE: The Technician will note if the repair APPEARS to be a warranty or non-warranty issue based on customer description of the issues at hand. No final determination can be made until inspection and testing of the equipment is completed at the factory.

- 4. To ensure fast and effective repairs, customer is required to send:
 - Dakota Micro, Inc. product that technician has requested/deemed necessary in the proper diagnosis and repair of
 malfunction. This may include some or all components of the kit.
 - Original/Copy of purchase receipt.
 - For serialized items ONLY, if a copy of the original purchase receipt cannot be provided, then Dakota Micro, Inc. will
 use the product manufacture date.
 - Customer information, including return address, phone number & email address.
 - Case Number provided by Dakota Micro, Inc. technical support
 - Shipping and associated costs to ship product to Dakota Micro, Inc. factory to be borne by the customer unless
 otherwise specified.
- 5. Customer should mail product to:

Dakota Micro, Inc. Case # XXXX 8659 148 ½ Ave. SE Cayuga, ND 58013

- 6. Upon receipt and evaluation of product at Dakota Micro, Inc. factory, it will be established if the repair is warranty or nonwarranty. Customer will be notified of any applicable charges.
- 7. If the repairs are deemed non-warranty and require a service/repair fee of any kind, a credit card number will be required.
- If customer is unable to be contacted over the course of 3 weeks regarding required non-warranty repairs, product will be held for 30 days and, if no response from customer, product will be discarded.
- 9. Any product returned without proper documentation may be returned at customer's expense.
- 10. Product returned with unconfirmed problems may be assessed an evaluation fee of up to \$60 per unit.
- 11. Return shipping costs will be borne by the party at fault; in other words, if Dakota Micro, Inc. determines that the defective product was covered under warranty, Dakota Micro, Inc. pays the shipping charges. If Dakota Micro, Inc. determines that it was the customers fault, the customer will pay shipping charges. If a particular circumstance cannot be determined then the cost of shipping charges will be decided on a discretionary basis depending on the situation at hand.



Consumer Limited Warranty

Subject to the disclaimer, limitations and other directions stated hereafter, Dakota Micro, Inc. warrants that the Product will be free from defects in material and workmanship for periods as stated hereafter from the date of original purchase. THIS WARRANTY IS EXPRESSLY MADE IN LIEU OF ANY AND ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS. THE EXCLUSIVE REMEDY OF THE BUYER IS LIMITED TO REPAIR OR REPLACEMENT OF THE PRODUCT. EXCEPT AS STATED IN THIS WARRANTY, DAKOTA MICRO, INC. SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY, NEGLIGENCE, STRICT LIABILITY OF ANY OTHER LEGAL THEORY. Any oral statements or representations made by anyone which are contrary to or at variance with the terms stated in this LIMITED WARRANTY are void.

Dakota Micro, Inc. will, at its option, either repair the defect or replace the defective Product or part thereof with a new or remanufactured equivalent at no charge to the purchaser for parts or labor for the period of five (5) years for AgCam[®] /EnduraCam[®] cameras; three (3) years for InnoPro[®] cameras; two (2) years for AgCam[®] / EnduraCam[®] monitors, and Wireless components; Twelve (12) Months for all Overview[®] and RazerCam[™] Cameras & Monitors, cables and all other accessories.

In addition to the five (5) years for AgCam[®] /EnduraCam[®] cameras Dakota Micro will warranty for the life of the camera against any variety of ingress within the camera housing. This includes moisture and dust particles that are found inside the camera resulting from a manufacturing defect and does not include ingress because of damage caused by no fault of Dakota Micro, Inc.

The Dakota Micro, Inc. limited warranty periods outlined above apply throughout the United States and Canada only. A one (1) year maximum limited warranty for all Products applies to all other geographic locations unless otherwise stated in writing by Dakota Micro, Inc.

This limited warranty does not apply to any issues connected with appearance that have no relation to the performance of the Product nor to any Product the exterior of which has been damaged or defaced, which has been subjected to improper voltage or other misuse, abnormal service or handling, or which has been altered or modified in design or construction.

In order to enforce the rights under this limited warranty, the purchaser should follow the process set forth in the Product Warranty/Repair Process, and provide proof of purchase to Dakota Micro, Inc.

Neither the sales personnel of Dakota Micro, Inc. nor any dealer or any other person is authorized to make any warranties other than those described herein, or to extend the duration of any warranties beyond the time periods described herein.

The warranties described herein shall be the sole and exclusive warranties and remedies provided by Dakota Micro, Inc. Correction of defects, in the manner and for the period of time described herein, shall constitute complete fulfilment of all liabilities and responsibilities of Dakota Micro, Inc. to the purchaser with respect to the Product, and shall constitute full satisfaction of all claims. In no event shall Dakota Micro, Inc. be liable or in any way responsible for any damages or defects in the Product which were caused by repairs or attempted repairs performed by anyone other than Dakota Micro, Inc.

Some states do not allow the limitation or exclusion of incidental or consequential damages, so said limitation may not apply to you.

Any action at law, suit in equity, or other judicial proceeding for the enforcement of any right provided for herein or otherwise, or with respect to any claim that a purchaser may have against Dakota Micro, Inc. shall be instituted only in the Courts of the State of North Dakota, either in the state district court located in Wahpeton, North Dakota or in Federal District Court located in Fargo, North Dakota. Without regard to conflicts of law principles, the laws of the state of North Dakota shall govern the interpretation and enforcement of the terms of this Limited Warranty and all aspects of the relationship between Dakota Micro, Inc., and the purchaser.

This warranty gives you specific legal rights and you may also have other rights, which may vary from state to state.

Disclaimer

Dakota Micro Inc. products, specifications, pricing, and programs are subject to change without prior notice. Dakota Micro Inc. reserves the right to make design changes at any time without obligation to retroactively install them on previously sold units.

Contact Us

